

● INSTALLATION INSTRUCTIONS:

Please read out step-by-step instructions carefully before installing your new sink strainer

INSTRUCTIONS

1. Clean the area around the opening in sink.
2. Remove locknut, coupling nut and washer from strainer body.
3. Spread 1/16" layer of plumbers putty under edge of strainer flange.
4. Insert strainer body A into sink opening and position flange firmly.
5. Attach rubber washer B and paper washer C onto strainer on underside of sink.
6. Thread locknut D to bottom of sink against washers, holding strainer body in place inside sink.
7. Tighten locknut by tapping lugs with a hammer and screw driver.
8. Wipe excess putty from around flange.
9. Tailpiece washer E on flange of tailpiece F, and attach slip nut G to bottom of strainer and tighten.
10. Connect trap to bottom of tailpiece.
11. Run water. check position of water and retighten if there is a leak.

NO.	DESCRIPTION
A	BODY
B	RUBBER WASHER
C	PAPER WASHER
D	LOCK NUT
E	TAILPIECE WASHER
F	TAILPIECE
G	SLIP NUT
H	BASKET

